



Service•Assistenza•Dienstvo•Servis

Servis•Serviz•Сервисная служба

Name• Nom • Nome • Naam •
Nazwa•Jméno•Názov•Név•
Denumire•İsim •Название

Nr. • No • N° • Номер • C • Sz
753430, 755832, 793397, 795463

Typ• Type• Tip•
Tipus• Tipo• Тип•



(D) Montageanleitung

(FR) Notice de montage

(NL) Handleiding voor de montage

(CZ) Montážní návod

(HU) Szerelési útmutató

(TR) Montaj talimatı

(GB) Assembly instructions

(IT) Istruzioni di montaggio




(PL) Instrukcja montażu

(SK) Návod na montáž


(RO) Instrucţiuni de montaj

(RU) Инструкция по монтажу



(HR) Shema montaže





Art.Nr. 753430, 755832
 Art.Nr. 793397, 795463
 LKZ 40827



30 min





1.




x4

2.




DETAIL a




x4

3.



DETAIL b



Die Unterseite der Platte mit Packmaterial (Karton oder Folie) verdecken, damit die Metallteile den Ablageboden nicht beschädigen.

