





Hamilton



- | | |
|-----------------------------|----------------------------------|
| (D) Montageanleitung | (GB) Assembly instructions |
| (FR) Notice de montage | (NL) Handleiding voor de montage |
| (CZ) Montážní návod | (IT) Istruzioni di montaggio |
| (RO) Instrucțiuni de montaj | (RU) инструкция по сборке |
| (PL) Instrukcja montażu | (SK) Návod na montáž |
| (HU) Szerelési útmutató | (TR) Montaj talimati |



Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denumire • Ísim • Название





**Hamilton
EB**

Nr. • No. • N° • Номер • Č • Sz

SH42

Typ • Type • Tip • Típus • Тип
Тип

OHNE



A	B	C	D
2x	2x 8x60	2x M8	2x M8

Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denumire • Ísim • Название




**Hamilton
EB**

Nr. • No. • N° • Номер • Č • Sz



SH42

Typ • Type • Tip • Típus • Тіро
Тип


LARO



A	B	C	D
			
2x	2x 8x60	2x M8	2x M8





B	C	D
		
2x 8x60	2x M8	2x M8

