










ISK51-8E

ISK61-8E



Service-Hotline
01805-678101
0,14€ pro Min.
++49 für Österreich
Auslandstarif pro Min.
Service@jaka-bkl.de
voor Nederland en België
00800-40119350
benelux@jaka-bkl.de

Montageanleitung



Ersatzteile/Spare parts/pièces de rechange/Reserveonderdelen/Piezas de recambio/Ricambi/Запасные части/Części zamienne/póalkatrészek/Náhradní díly/Nadomestni deli/Varicosat/resen/delar/náhradné diely/Utilizaj please de schimb/V edek parçalar

- ISK51-8E J E941934 Q Q1 E946007 R E941932 S S1 E946007 T E941937 W W1 E946008 W1 E946009
- ISK61-8E J E941935 Q Q1 E946007 R E941933 S S1 E946007 T E941938 W W1 E946008 W1 E946009