





Art. Nr.









2156 7604; 6718 8406

LKZ 40947



- | | | | |
|-----------|------------------------------------|-----------|--------------------------------|
| D | Montageanleitung | GB | Assembly instructions |
| FR | Notice de montage | IT | Istruzioni di montaggio |
| NL | Handleiding voor de montage | PL | Instrukcja montażu |
| CZ | Montážní návod | SK | Návod na montáž |
| HU | Szerelési útmutató | RO | Instrukțiuni de montaj |
| TR | Montaj talimatı | RU | Инструкция по монтажу |









№	Size/MaB (mm)	Qty	✓	№	Size/MaB (mm)	Qty	✓
1	1021x498x52	1		5	445x413x16	1	
2	1021x498x52	1		6	325x61x20	1	
3	274x40x30	1		7	253x61x30	1	
4	567,5x41x29	3		8			

1

B 230010
8x32 x13C 250012
3,5x15 x4D 180073
25x25x15 x4



2

G 070004
x1G 070004
x1


3

A 030039
7x70 x3F 110022
SW 4 x1

4

A 030039
7x70 x3F 110022
SW 4 x1



5



6

C 250012
3,5x15 x4

E 070017
30x30 x4



7

H 070045
Home x1

