



KAHEKILI WNL





LKZ 042289








- | | |
|---------------------------------------|-----------------------------------|
| D Montageanleitung | GB Assembly instructions |
| FR Notice de montage | IT Istruzioni di montaggio |
| NL Handleiding voor de montage | PL Instrukcja montażu |
| CZ Montážní návod | SK Návod na montáž |
| HU Szerelési útmutató | RO Instrucțiuni de montaj |
| TR Montaj talimatı | RU Инструкция по монтажу |








A M8x70	B 5x35	C M 6x45	D H 50	E	F „5”	G „4”
						
x2	x13	x4	x13	x13	x1	x1



1



2






3





B	5x35	D	H 50	E
				
x6		x6		x6

4



C	M 6x45	G	„4”
			
x4		x1	

5




A M8x70

F „5”




x2





x1

6





1





B	5x35	D	H 50	E
				
x5		x5		x5

2





B	5x35	D	H 50	E
				
x2		x2		x2

3





B	5x35	D	H 50	E
				
x6		x6		x6


4




C	M 6x45	G	„4“
			
x4		x1	

5



A	M8x70	F	„5”
	x2		x1

6



Service • Assistenza • Dienstverlening • Serwis •
Servis • Szerviz • Сервисная служба




Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denumire • İsim • Имя

KAHEKILI

Nr • No. • N° • Номер • Č • Sz

Typ • Tipo • Тип • Typ •
Típus • Тип

WNL



A M8x70




X...

B 5x35



X...

C M 6x45



X...

D H 50




X...

E




X...

F „5”



X...

G „4”



X...