


CHELSEA HOCKER 80x80



(D) Montageanleitung

(NL) Handleiding voor de montage

(TR) Montaj talimatı

(F) Notice de montage

(CZ) Montážní návod

(GB) Assembly instructions

(HU) Szerelési útmutató




(PL) Instrukcja montażu

(RU) Инструкция по монтажу


(IT) Istruzioni di montaggio

(SK) Návod na montáž


(RO) Instrucțiuni de montaj




x1




x4








x24



x1











0-6



Service • Assistenza • Dienstverlening • Serwis • Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam • Nazwa • Jméno • Názov • Név • Denumire • Isim • Название	CHELSEA
Nr • No. • N° • Номер • Č • Sz	80x80
Type • Tipo • Tipus • Typ • Тип • Тип	HOCKER



A		X...
B		X...
C		X...
D		X...