






Art. Nr. 28123335; 79864511

LKZ 40947








- | | |
|---------------------------------------|------------------------------------|
| D Montageanleitung | GB Assembly instructions |
| FR Notice de montage | IT Istruzioni di montaggio |
| NL Handleiding voor de montage | PL Instrukcja montażu |
| CZ Montážní návod | SK Návod na montáž |
| HU Szerelési útmutató | RO Instrucțiunile de montaj |
| TR Montaj talimatı | RU Инструкция по монтажу |











№	Size/MaB (mm)	Qty	✓	№	Size/MaB (mm)	Qty	✓
1	1800x 400x 24	1		10	282x 42x 12	4	
2	1706x 362x 15	1		11	330x 318x 18	2	
3	526x 383x 50	1		12	964x 140x 18	1	
4	526x 383x 50	1		13	350x 100x 14	1	
5	375x 366x 15	1		14	350x 100x 14	1	
6	375x 366x 15	1		15	934x 100x 14	1	
7	968x 375x 15	1		16	943x 342x 3	1	
8	1666x 42x 18	1		17	982x 385x 3	1	
9	1666x 60x 18	1		18	385x 350x 3	2	



3	A 030093 x6	C 230010 Ø8x32 x4	L 180098 x4	M 250012 3,5x15 x40	N 250018 3,5x25 x8
---	-----------------------	-----------------------------	-----------------------	-------------------------------	------------------------------




4	B 030110 x30	R 070017 30x30 x4
---	------------------------	-----------------------------




5

H 220043 x2



6



7

