


|    |                   |    |                         |    |                             |    |                    |    |                    |    |                        |
|----|-------------------|----|-------------------------|----|-----------------------------|----|--------------------|----|--------------------|----|------------------------|
| D  | Montageanleitung  | GB | Assembly Instructions   | NL | Handleiding voor de montage | PL | Instrukcja montażu | HU | Szerelési útmutató | RO | Instrucțiuni de montaj |
| FR | Notice de montage | IT | Istruzioni di montaggio | CZ | Montážní návod              | SK | Návod na montáž    | TR | Montaj talimatı    | RU | Инструкция по монтажу  |


Service • Assistenza • Dienstverlening • Serwis  
Servis • Szerviz • Сервисная служба

Schuhbank









5.9125



|    |     |               |   |
|----|-----|---------------|---|
| 1. | AS  | 452x330x15mm  | 2 |
| 2. | MS  | 452x315x15mm  | 1 |
| 3. | BL  | 1046x350x15mm | 2 |
| 4. | TR  | 346x446x15mm  | 3 |
| 5. | EBG | 674x314x15mm  | 2 |
| 6. | EBK | 326x314x15mm  | 2 |
| 7. | RW  | 1026x464x3mm  | 1 |



|     |                  |     |     |                    |     |
|-----|------------------|-----|-----|--------------------|-----|
| A5  | 0mm              | 4x  | s3  | 4x21               | 6x  |
| A6  | 8mm              | 2x  | s6  | 4x27               | 6x  |
| B1  |                  | 6x  | r   |                    | 16x |
| e11 | 24,3             | 12x | v   |                    | 3x  |
| f1  |                  | 12x | x   | Ø=45mm<br>Möbelfuß | 6x  |
| h4  | Stopfen<br>Ø=5mm | 6x  | y14 |                    | 8x  |
| n   | 8x30mm           | 12x | z   |                    | 10x |



|     |      |     |
|-----|------|-----|
| A5  | 0mm  | 4x  |
| A6  | 8mm  | 2x  |
| B1  |      | 6x  |
| e11 | 24,3 | 12x |

