



70003068; 58355728; 38273369


99460456; 70378462; 81035345





54203336; 44274061; 84848821

LKZ 40947



- | | |
|---------------------------------------|-----------------------------------|
| D Montageanleitung | GB Assembly instructions |
| FR Notice de montage | IT Istruzioni di montaggio |
| NL Handleiding voor de montage | PL Instrukcja montażu |
| CZ Montážní návod | SK Návod na montáž |
| HU Szerelési útmutató | RO Instrucțiuni de montaj |
| TR Montaj talimatı | RU Инструкция по монтажу |





x4

Art. Nr. 70003068; Art. Nr. 58355728; Art. Nr. 38273369

No	Size/MaB (mm)	Qty	✓	No	Size/MaB (mm)	Qty	✓
1	1600x800x128	1		2	730x100x100	4	

Art. Nr. 99460456; Art. Nr. 70378462; Art. Nr. 81035345

No	Size/MaB (mm)	Qty	✓	No	Size/MaB (mm)	Qty	✓
1	1800x900x128	1		2	730x100x100	4	

Art. Nr. 54203336; Art. Nr. 44274061; Art. Nr. 84848821

No	Size/MaB (mm)	Qty	✓	No	Size/MaB (mm)	Qty	✓
1	2000x100x128	1		2	730x100x100	4	

1

