

D Montageanleitung

GB Assembly Instructions

NL Handleiding voor de montage

PL Instrukcja montażu

HU Szerelés útmutató

RO Instrucțiuni de montaj

FR Notice de montage

IT Istruzioni di montaggio

CZ Montážní návod

SK Návod na montáž


TR Montaj talimatı

RU Инструкция по монтажу












Service • Assistenza • Dienstverlening • Serwis

Servis • Szerviz • Сервисная служба

Наименование	Flint
Артикул	7.7540
Тип	7.7540




101.	ASL	833x330x15mm	1
21.	ASR	833x330x15mm	1
31.	BL	500x330x15mm	1
41.	BD	500x330x15mm	1
5.	BLE	499x61x15mm	1
61.	ZB	469x315x15mm	1
7.	EB	469x315x15mm	1
8.	TR	496x638x15mm	1
9.	SKV	496x157x15mm	1
10.	SKB	445x278x3mm	1
11.	SZL	282x97x12mm	1
12.	SZH	434x97x12mm	1
13.	SZR	282x97x12mm	1
14.	RW	845x481x3mm	1




A5	0mm	2x
b3	KA37	2x
e11	24,3	8x
s6	4x27	4x
v		2x
f8	246 Auszug	2x
c	6,3x11 kurz	4x
n	8x30mm	8x



A5	0mm	2x	t6	3,5x30	8x
b3	KA37	2x	l	8x30mm	19x
c	6,3x11 kurz	4x	n	8x30mm	8x
e11	24,3	8x	q10	M4x9	2x
f1		8x	r	4x27	4x
f8	246 Auszug	2x	s6	4x27	4x
			z		5x




f1		4x
----	--	----




n	8x30mm	11x
y4		1x
f1		4x



l		4x
z		10x



t6	3,5x30	8x
x8	Fuß 58x40	4x
y14		10x



r		4x
q10	M4x9	2x

