





MISTRAL

- design for your life


31029-E3




PZ2




F1 x 4
(6005170)




F2 x 8
(6700503)



F3 x 2
(6005110)




F4 x 2
(6005120)



F5 x 8
(6603215)



F6 x 2
(4005361)




F7 x 2
(6704422)




F8 x 2
(6200210)

F20 x 4
(M4 x 10 mm)




F21 x 4
(M4 x 12 mm)



F22 x 4
(M4 x 16 mm)




F23 x 4
(Ø5 x 14 mm)




A




B




C




D








31029-E3-P1 /5







1














2




3




4







1




2




3



4




5



6

L=venstre/left/links/gauche/vänstre
R= højre/right/rechts/droit/höger



(F9).
Anvend kun 2xL* eller 2xR* pr. dør.
Only use 2xL* or 2xR* covers f/1 door.
Nur 2xL* oder 2xR* per Tür anwenden.
Utilisez seulement 2xL* ou 2xR* par porte.
Använd endast 2xL* eller 2xR* lock/dörr.