






Art. Nr.2970 4211

LKZ 41164




- | | |
|----------------------------------|------------------------------|
| (D) Montageanleitung | (GB) Assembly instructions |
| (FR) Notice de montage | (IT) Istruzioni di montaggio |
| (NL) Handleiding voor de montage | (PL) Instrukcja montazu |
| (CZ) Montážní návod | (SK) Návod na montáž |
| (HU) Szerelési útmutató | (RO) Instrucțiuni de montaj |
| (TR) Montaj talimati | (RU) Инструкция по монтажу |






A
000131

M8
x4




B
002706

M6x30
x24



C
230041

22x16
x4




D
284846

x4



E
153722

x12



F
238966

x1




N	LxBxH (mm)	Qty	✓	N	LxBxH (mm)	Qty	✓
1	1000x400x16	1		2	962x342x16	2	
				3	722x112x20	4	

Service - Dienstverlening - Serwis - Servis - Сервисная служба

Name - Naam - Nazwa - Isim - Название


Nr. - No. - Номер

Typ - Type - Тип - Тип



1

x4



2

