

Angara



D Montageanleitung

GB Assembly instructions

FR Notice de montage

NL Handleiding voor de montage

CZ Montážní návod

IT Istruzioni di montaggio

RO Instrucțiuni de montaj





RU инструкция по сборке

PL Instrukcja montażu

SK Návod na montáž

HU Szerelési útmutató

TR Montaj talimatı



Service • Assistenza • Dienstverlening • Servis

Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denumire • İsim • Название




Angara DB

Nr. • No. • N° • Номер • Č • Sz

SH52

Typ • Type • Tip • Típus • Tipo
Тип

OHNE



A	B	C	D	E	F	G	H	I	J	K	L	M
4x	4x 8x50	4x 10x80	4x 8x20	5x M6	5x M6	5x M6	5x	2x	4x	4x 8x60	4x 8x40	4x M8

Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denumire • İsim • Название



Angara DB

Nr. • No. • N° • Номер • Č • Sz

SH52


Typ • Type • Tip • Típus • Tipo
Тип


LARO





A	B	C	D	E	F	G	H	I	J	K	L	M
4x	4x 8x50	4x 10x80	4x 8x20	5x M6	5x M6	5x M6	5x	2x	4x	4x 8x60	4x 8x40	4x M8




A	B	C	D
			
4x	4x 8x50	4x 10x80	4x 8x20





E		F		G		H		I		J	
5x 6x45		5x M6		5x M6		5x M6		2x		4x	





Achtung! Schrauben nicht überdrehen		Watch Out! Do not over tighten	
FR Attention! Ne serrez pas trop		NL Let Op! Niet te vast	
CZ Dávej Pozor! Nepřetahujte		IT Attento! Non stringere	
RO Ai Grijai! Nu strângeți		RU Осторожно! Не затягивайте	
PL Uwaga! Nie dokręcać zbyt mocno		SK Dávaj Pozor! Nepreťahujte	
HU Vigyázz! Ne húzza túl		TR Dikkat! Üzerinde sıkmayın	
K	L	M	
			
4x 8x60	4x 8x40	4x M8	

