

(D) Montageanleitung

(GB) Assembly instructions

(NL) Handleiding voor de montage

(PL) Instrukcja montażu

(HU) Szerelési útmutató

(RO) Instrucțiuni de montaj

(FR) Notice de montage

(IT) Istruzioni di montaggio

(CZ) Montážní návod

(SK) Návod na montáž




(TR) Montaj talimatı

(RU) Инструкция по монтажу


Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam Nazwa • Jméno • Název • Nev Denimke • Ism • Название	MZ
Nr • No • N° • Номер • C • Sz	
Tür • Type • Tip • Tipus • Tipo Typ	4.0101

- | | | |
|----|------------------|---|
| 1. | AS 1732x370x15mm | 2 |
| 2. | BL 800x390x15mm | 2 |
| 3. | ZB 768x354x15mm | 2 |
| 4. | EB 768x354x15mm | 5 |
| 5. | TR 1726x396x15mm | 2 |
| 6. | RW 871x780x3mm | 2 |



Ø10mm



A5	0mm	6x	s3	4x21	4x
B1		6x	s6	4x27	4x
k9	Blattschraube	2x	t1	3,5x15	2x
l		16x	v		2x
ll		8x	x	Ø=40mm	4x
r		20x	z		20x

