


LINCOLNVILLE WNL



D Montageanleitung

GB Assembly instructions

FR Notice de montage

IT Istruzioni di montaggio

NL Handleiding voor de montage

PL Instrukcja montażu

CZ Montážní návod



SK Návod na montáž

HU Szerelési útmutató

RO Instrucțiuni de montaj






TR Montaj talimatı

RU Инструкция по монтажу







A M8x75 x4	B M8x22 x8	C M8 x6	D M8x70 x2	E x14	F 4 x1	G 5 x1
H x14	I „13” x1	J M 6x45 x4				









1








2











3




4









1



4x



E




x4


H




x4



2



4x



F



4

x1








J








M 6x45




x4



3



4







Service • Assistenza • Dienstverlening • Serwis •
Servis • Szerviz • Сервисная служба





Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denimire • İsim • Имя






LINCOLNVILLE

Nr • No. • N° • Номер • Č • Sz

Typ • Tipo • Тип • Typ •
Тип • Тр

WNL



A	M8x75	B	M8x22	C	M8	D	M8x70	E		F	4	G	5
	X...		X...		X...		X...		X...		X...		X...
H		I	"13"	J	M 6x45								
	X...		X...		X...								