

Montageanleitung

GB Assembly Instructions

Handhaving voor de montage

 Instrukcijski montažu

 Szerelex útszolgálat

RO Instrucțiuni de montaj

FR Notice de montage



II Istruzioni di montaggio

Northland aliyod




 Návod na montáž







Montaj talimatı


RU Инструкция по монтажу



- | | | | |
|----|----|--------------|---|
| 1. | AS | 484x320x15mm | 2 |
| 2. | BL | 650x320x15mm | 1 |
| 3. | BD | 650x320x15mm | 1 |
| 4. | TR | 478x306x15mm | 2 |
| 5. | RW | 630x160x3mm | 1 |



A7		4x	n9		1x
b3		4x	s6		4x
e11		8x	t4		8x
f1		8x	v		2x
h		1x	x8		4x
n		8x	y14		6x





A7		4x
b3		4x
e11		8x
n9		1x
s6		4x
v		2x
h		1x


1

f1		4x
n	8x30mm 	8x

2





5



3

f1		4x
----	--	----

4



y14		6x
t4	3,5x25 	8x
x8	Fuß 58x40 	4x

