






BENDIGO V
2501-0037/8242
8241/2503-0037




201101

D	MONTAGEANLEITUNG BEDIENUNGSANLEITUNG	GB	ASSEMBLY INSTRUCTIONS INSTRUCTION MANUAL
NL	HANDLEIDING VOOR DE MONTAGE GEBRUIKSAANWIJZING	PL	INSTRUKCJA MONTAŻU INSTRUKCJA OBSŁUGI
TR	MONTAJ TALIMATI KULLANIM KILAVUZU	RU	ИНСТРУКЦИЯ ПО МОНТАЖУ ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ
RO	INSTRUCȚIUNI DE INSTALARE INSTRUCȚIUNI DE UTILIZARE	IT	ISTRUZIONI DI MONTAGGIO MANUALE DI ISTRUZIONI
FR	NOTICE DE MONTAGE MANUEL INSTRUCTIONS	SK	MONTÁŽNY NÁVOD NÁVOD NA POUŽITIE
HU	KÖZGYŰLÉS UTASÍTÁSOK KEZELÉSI UTASÍTÁS	CZ	MONTÁŽNÍ NÁVOD NÁVOD K POUŽITÍ
SI	NAVODILA ZA MONTAŽO NAVODILA ZA UPORABO	PT	INSTRUÇÕES DE MONTAGEM MANUAL DO USUÁRIO
ES	INSTRUCCIONES DE MONTAJE MANUAL DEL USUARIO	HR	UPUTE ZA MONTAŽU UPUTE ZA UPOTREBU



R







L










y _{H-120/150} X1	z _{H(120-180)} X2	s Fi- 35 X1	x _{H-120/150} X3	q M6*25 X12	i L- 4 X1	[mm]
---	--	---------------------------	---	---------------------------	-------------------------	------






z _{H(120-180)} X2	x _{H-120/150} X2	q M6*25 X8	i L- 4 X1
--	---	--------------------------	-------------------------



y H-120/150 	z H(120-180) 	s Fi- 35 	x H-120/150 	q M6*25 	i L- 4 
X1	X4	X1	X5	X20	X1











Name · Naam · Nazwa · İsim · Название · Nume · Nome · Názov · Názov ·
Název · Neve

BENDIGO V


Typ · Type · Tip · Тип · Tipo · Típus



R



L



y H-120/150 	z H(120-180) 	s Fi- 35 	x H-120/150 	q M6*25 	i L- 4

