


















Art. Nr. 313337; 341337

LKZ 40947







- | | | | |
|-----------|-----------------------------|-----------|-------------------------|
| D | Montageanleitung | GB | Assembly instructions |
| FR | Notice de montage | IT | Istruzioni di montaggio |
| NL | Handleiding voor de montage | PL | Instrukcja montażu |
| CZ | Montážní návod | SK | Návod na montáž |
| HU | Szerelési útmutató | RO | Instrucțiuni de montaj |
| TR | Montaj talimatı | RU | Инструкция по монтажу |










No	Size/MaB (mm)	Qty	✓	No	Size/MaB (mm)	Qty	✓
1	900x 670x 24	1		7	356x 56x 18	2	
2	811x 586x 15	1		8	739x 56x 24	2	
3	586x 356x 15	2		9	512x 56x 24	2	
4	733x 294x 18	2		10	739x 56x 18	2	
5	120x 60x 60	4		11	116x 24x 24	4	
6	356x 56x 18	2					
















4



5



4