






LKZ 40605



- | | | | |
|-----------|------------------------------------|-----------|--------------------------------|
| D | Montageanleitung | GB | Assembly instructions |
| FR | Notice de montage | IT | Istruzioni di montaggio |
| NL | Handleiding voor de montage | PL | Instrukcja montażu |
| CZ | Montážní návod | SK | Návod na montáž |
| HU | Szerelési útmutató | RO | Instrukțiuni de montaj |
| TR | Montaj talimatı | RU | Инструкция по монтажу |





Service · Dienstverlening · Serwis · Servis · Сервисная служба



Name · Naam · Nazwa · Isim · Название





Nr. · No. · Номер

Typ · Type · Tip · Тип







N	Size/MaB (mm)	Qty	✓
1	1000x1000	1	
2	980x440	4	
3	708x708	1	
4	940x25	2	





2



3

