






LKZ 40605



- | | | | |
|-----------|------------------------------------|-----------|--------------------------------|
| D | Montageanleitung | GB | Assembly instructions |
| FR | Notice de montage | IT | Istruzioni di montaggio |
| NL | Handleiding voor de montage | PL | Instrukcja montażu |
| CZ | Montážní návod | SK | Návod na montáž |
| HU | Szerelési útmutató | RO | Instrukțiuni de montaj |
| TR | Montaj talimatı | RU | Инструкция по монтажу |





Service · Dienstverlening · Serwis · Servis · Сервисная служба









Name · Naam · Nazwa · Isim · Название

Nr. · No. · Номер


Typ · Type · Tip · Тип



N	Size/MaB (mm)	Qty	✓
1	1000x500	1	
2	1000x500	1	
3	1000x500	1	
4	360x20	4	
5	420x20	2	



1



2

