




Lotus



- | | |
|-----------------------------|----------------------------------|
| (D) Montageanleitung | (GB) Assembly instructions |
| (FR) Notice de montage | (NL) Handleiding voor de montage |
| (CZ) Montážní návod | (IT) Istruzioni di montaggio |
| (RO) Instrucțiuni de montaj | (RU) инструкция по сборке |
| (PL) Instrukcja montażu | (SK) Návod na montáž |
| (HU) Szerelési útmutató | (TR) Montaj talimati |



Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denumire • İsim • Название



Lotus zerl.

Nr. • No. • N° • Номер • Č • Sz

SH55

Typ • Type • Tip • Típus • Tipo
Тип


OHNE



7



1



3

5



4

6


2

8




A	B	C	D	E	F	G	H	I	J	K	L	M
2x	16x 6x20	4x 8x60	6x 8x20	6x M8	2x 6x30	2x M6	2x 5x16	2x M5	2x 4,5x20	10x 6x35	2x	2x 8x45

1.



EW
 Handfest anziehen
 Ne serrez pas
 Nedotahujte
 Nu strângeți
 Nie dokrećać
 Ne húzza meg
 Do not tighten
 Nog niet vastdraaien
 Non serrare
 Не затягивайте
 Nedotahujte
 Sıkmayın




= 2x




2.

1 und 2 + 4



+5




Schrauben fest anziehen
 Serrer les vis
 Utáhněte šrouby
 Strângeți șuruburile
 Dokrećić šrubby
 Húzza meg a csavarokat
 Tighten the screws
 Draai de schroeven
 Serrare le viti
 Затянуть винты
 Utiahnite skrutky
 Vidaları sıkın



3.




4.




5.





C	D	E
		
4x 8x60	4x 8x20	4x M8



KT_4xGEW_8x60