



(D) Montageanleitung

(GB) Assembly instructions

(FR) Notice de montage

(TR) Montaj talimatı

(IT) Istruzioni di montaggio

(NL) Handleiding voor de montage

(RU) Инструкция по монтажу


(CZ) Montážní návod

(HU) Szerelési útmutató

(RO) Instrucțiuni de montaj

(PL) Instrukcja montażu

(SK) Návod na montáž



0205_A-2er Untergestell/A

REPC-Nr.:

Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба

			<p>Colli 1/1: (1) (2) (3) Beutel 1/2, 2/2</p>

Beutel 1/2




1-172		1-180	
16x	4.5x40	16x	6x45

Beutel 2/2


1-241		1-242		1-360		1-362		1-364		2-104	
1x	SW 5	1x	SW 6	4x		4x	6x50	4x		8x	8x40
2-166		5-130									
16x		1x	LEIM								




Colli 1/1




1	1-242		1-360	
	1x	SW 6	4x	
	2-104		2-166	
8x	8x40	16x		
5-130		1		
1x	LEIM			



2	1-241		1-362	
	1x	SW 5	4x	6x50



3



4

1-364	
4x	

