





- (D) Montageanleitung
- (NL) Handleiding voor de montage
- (HU) Szerelési útmutató
- (GB) Assembly instructions
- (PL) Instrukcja montażu






- (RO) Instrucțiuni de montaj
- (TR) Montaj talimatı
- (IT) Istruzioni di montaggio
- (SK) Návod na montáž
- (RU) Инструкция по монтажу
- (FR) Notice de montage
- (CZ) Montážní návod

Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба


Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denumire • İsim • Название

Nr. • No. • N° • Номер • Č • Sz

Typ • Type • Tip • Típus • Tipo •
Тип




1	1x	ca. 1665 x 330 mm
2	1x	ca. 1644 x 680 mm
3	1x	ca. 1665 x 330 mm
4	1x	ca. 668 x 330 mm
5	1x	ca. 668 x 315 mm
6	1x	ca. 668 x 315 mm
7	1x	ca. 668 x 330 mm
8	1x	ca. 639 x 60 mm
9	1x	ca. 1665 x 60 mm
10	1x	ca. 639 x 60 mm
11	2x	ca. 398 x 476 mm
12	3x	ca. 737 x 156 mm
13	3x	ca. 707 x 307 mm
14-L	3x	ca. 310 x 88 mm
14-M	3x	ca. 695 x 88 mm
14-R	3x	ca. 310 x 88 mm
15	1x	ca. 728 x 315 mm
16	2x	ca. 438 x 315 mm
17	1x	ca. 858 x 330 mm
18	1x	ca. 858 x 330 mm
19	2x	ca. 145 x 304 mm
20	1x	ca. 2193 x 60 mm
21	1x	ca. 813 x 60 mm
22	1x	ca. 813 x 60 mm
23	1x	ca. 2193 x 330 mm
24	2x	ca. 437 x 300 mm
25	4x	ca. 244 x 310 mm



A 8,0 x 30 mm 70x	B 54x	C 62x	D 7x	E 3,9 x 9,5 mm 14x	F 3,5 x 13 mm 16x	G 1x
H 4x	I 8x	J 4,0 x 20 mm 8x	K 2,7 x 20 mm 8x	L 17 x 310 mm 6x	M 6,3 x 13 mm 12x	N M4,0 x 9 mm 6x
O 80 mm 4x	P 16x	R 8x	S 6,3 x 50 mm 6x			





MA2







1 = ~~X~~ ☹️

1






3 = 😊 ✓
















2




A 8,0 x 30 mm  12x	B  22x	C  10x	S 6,3 x 50 mm  6x
---	--	--	--




3



4	E 3,9 x 9,5 mm 12x	
A 8,0 x 30 mm 8x	C 8x	D 17 x 310 mm 6x
		M 6,3 x 13 mm 12x




5



1x

D Leim
GB Glue
FR Colle
IT Colla
NL Lijm
PL Klej
CZ Lepidlo
SK Glej
HU Enyv
RO Adeziv
TR Tutkal
RU Клей



3x

14-R

14-M

14-L



3x

14-R

13

14-L

14-M



3x


14-L

14-M

13


14-R

12






20min







6



H




H

11



2x **11**

7






B



H

8

10






8




9

K	2,7 x 20 mm
	8x
N	M4,0 x 9 mm
	6x
R	
	8x






➔ 15 / 16





- (D) Push-To-Open einstellen
- (GB) Adjusting the Push-To-Open
- (FR) Régler les Push-To-Open
- (IT) Sistemare Push-To-Open
- (NL) Push-To-Open instellen
- (PL) Nastawić Push-To-Open
- (CZ) Vyrovnajte Push-To-Open
- (RO) Nastavenie Push-To-Open
- (HU) Állítsa be az Push-To-Open
- (SK) Reglare Push-To-Open
- (TR) Push-To-Open ayarlanması
- (RU) Регулировка Push-To-Open

➔ 16 / 16






- (D) Türen einstellen (Scharniere justieren)
- (GB) Adjusting the doors (adjusting the hinges)
- (FR) Régler les portes (ajuster les charnières)
- (IT) Sistemare le porte (regolare le cerniere)
- (NL) Deuren instellen (scharnieren afstellen)
- (PL) Nastawić drzwi (wyregulować zawiasy)
- (CZ) Vyrovnajte dvířka (seřid'te závěsy)
- (RO) Nastavenie dverí (nastavenie závesov)
- (HU) Állítsa be az ajtókat (állítsa be a zsanérokat)
- (SK) Reglare uši (ajustare balamale)
- (TR) Kapıların ayarlanması (menteselerin seviye ayarı)
- (RU) Регулировка дверей (регулировка шарнира)


11



12











- | | |
|--|--|
| (D) Push-To-Open einstellen | (CZ) Vyrovnejte Push-To-Open |
| (GB) Adjusting the Push-To-Open | (RO) Nastavenie Push-To-Open |
| (FR) Régler les Push-To-Open | (HU) Állítsa be az Push-To-Open |
| (IT) Sistemare Push-To-Open | (SK) Reglare Push-To-Open |
| (NL) Push-To-Open instellen | (TR) Push-To-Open ayarlanması |
| (PL) Nastawić Push-To-Open | (RU) Регулировка Push-To-Open |

1.



2.





(D) Türen einstellen
(Scharniere justieren)

(GB) Adjusting the doors
(adjusting the hinges)

(FR) Régler les portes
(ajuster les charnières)

(IT) Sistemare le porte
(regolare le cerniere)

(NL) Deuren instellen
(scharnieren afstellen)

(PL) Nastawić drzwi
(wyregulować zawiasy)

(CZ) Vyrovnajte dvířka
(seřid'te závěsy)

(RO) Nastavenie dverí
(nastavenie závesov)

(HU) Állítsa be az ajtókat
(állítsa be a zsanérokat)

(SK) Reglare uši
(ajustare balamale)

(TR) Kapıların ayarlanması
(menteşelerin seviye ayarı)

(RU) Регулировка дверей
(регулировка шарнира)

