


Art. No. 33286304, 57252716, 31010211, 75308838, 34984239, 93338425, 91129310, 24849028, 90360527, 33592463, 13201627, 47517055, 32040257, 88623308, 11080962, 68043616, 23290356, 23253268, 79558525, 24648033, 13419519, 60756922, 22150937, 77848817

Marseille

chaiselong



(D) Montageanleitung

(FR) Notice de montage

(NL) Handleiding voor de montage

(CZ) Montážní návod

(HU) Szerelési útmutató

(TR) Montaj talimatı

(GB) Assembly instructions


(IT) Istruzioni di montaggio

(PL) Instrukcja montażu

(SK) Návod na montáž

(RO) Instrucțiuni de montaj

(RU) Инструкция по монтажу



LKZ 40937






**Service •Usługa •Обслуживание •Servizio •Un service
Serviciu •Služba •Servis •Szolgáltatás**

Name •Nom •Nome •Naam
•Nazwa •Název •Názov
•Név •Nume •Isim
•Название

Marseille

•Nr •No •N° •Номер •Č •Sz

33286304, 57252716, 31010211, 75308838, 34984239,
93338425, 91129310, 24849028, 90360527, 33592463,
13201627, 47517055, 32040257, 88623308, 11080962,
68043616, 23290356, 23253268, 79558525, 24648033,
13419519, 60756922, 22150937, 77848817



1

