




- | | | | |
|----|-----------------------------|----|-------------------------|
| Ⓛ | Montageanleitung | ⒼⒷ | Assembly instructions |
| ⒻⓇ | Notice de montage | ⒾⓉ | Istruzioni di montaggio |
| ⓃⓁ | Handleiding voor de montage | ⓅⓁ | Instrukcja montażu |
| ⒸⓏ | Montážní návod | ⓈⓀ | Návod na montáž |
| ⒽⓊ | Szerelési utmutató | Ⓡⓞ | Instrucțiuni de montaj |
| ⓉⓇ | Montaj talimatı | ⓇⓊ | Инструкция по монтажу |

Ausgabe: 20170826




0
10
20
30
40
50
60
70
80
90
100
110
120
130
140
150
160
170
180
190
200


Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба		
Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • Isim • Название	CHERLEN	
Nr. • No. • N° • Номер • Č. Sz	1842 2922 / 7599 9724	
Typ • Type • Tip • Típus • Tipo Тип		




A	M6X12MM	B	M4X20MM	C		D	
	X16		X16		X1		X4




1




A	M6X12MM  X16
C	 X1




2



B	M4X20MM  X16
D	 X4



3



4

