

(D) Montageanleitung

(FR) Notice de montage

(NL) Handleiding voor de montage

(CZ) Montážní návod

(HU) Szerelési útmutató

(TR) Montaj talimatı

RIVEO

(GB) Assembly instructions


(IT) Istruzioni di montaggio

(PL) Instrukcja montażu




(SK) Návod na montáž

(RO) Instrucțiuni de montaj

(RU) Инструкция по монтажу



2AL-RC



RC-2AL

P1 x6



P2 x2



P3 x4



(D) Montageanleitung

(FR) Notice de montage

(NL) Handleiding voor de n

(CZ) Montážní návod

(HU) Szerelési útmutató

(TR) Montaj talimatı

RIVEO

(GB) Assembly instructions


(IT) Istruzioni di montaggio

(PL) Instrukcja montażu




(SK) Návod na montáž

(RO) Instrucțiuni de montaj

(RU) Инструкция по монтажу





2AL-RC




RC-2AL

2AL





U1 S3




B1 S2

B1	S2	S3	U1
x2	x4	x2	x2

RC




S2 B2




S3 U1


B2	S2	S3	U1
x2	x4	x2	x2

RC



B2	S2	S3	U1
			
x2	x4	x2	x2

2AL











B1	S2	S3	U1
			
x2	x4	x2	x2

Service - Servis - Dienstverlening - Servis - Servis - Сервисная служба
Servizio - Service - Serviciu - Služby - Szolgálatás

Name - Nazwa - Naam - Name - Isim - Имя
Nome - Nom - Numele - Meno - Jméno - Neve

RIVEO
2AL-RC
RC-2AL



S2	M6/20	S3	M8/60	U1	K1	K2
						
X.....	X.....	X.....	X.....	X.....	X.....	X.....
B1	B2	P1	P2	P3		
						
X.....	X.....	X.....	X.....	X.....		