

D Montageanleitung

GB Assembly instructions

NL Handleiding voor de montage

PL Instrukcja montażu

HU Szerelési útmutató

RO Instrucțiuni de montaj

FR Notice de montage

IT Istruzioni di montaggio

CZ Montážní návod

SK Návod na montáž



TR Montaj talimatı

RU Инструкция по монтажу



Service • Assistenza • Dienstverlening • Serwis

Servis • Szerviz • Сервисная служба


Name • Nom • Nome • Naam Nazwa • Imię • Názov • Név Демиме • Ім'я • Назов • Нев	MZ
Nr. • No. • N° • Номер • C • Sz	
Typ • Type • Tip • Típus • Tipo	4.9122
?	



1.	AS	1732x370x15mm	2
2.	MS	1201x354x15mm	1
3.	BLB	800x390x15mm	2
4.	ZB	768x354x15mm	2
5.	EB	213x354x15mm	2
6.	TR	1726x396x15mm	2
7.	RW	1744x780x3mm	2



A5	0mm	6x
B1	4x21	6x
s3	4x27	4x
s6	3,5x15	4x
t1		4x
v		2x
v4		1x
x	Ø=40mm	4x



A5	0mm	6x	s3	4x21	4x
B1		6x	s6	4x27	4x
k9	Blattschraube	1x	t1	3,5x15	5x
l		20x	v		2x
l1		14x	v4		1x
r		8x	x	Ø=40mm	4x
r4	8x40	1x	z		20x

