



D Montageanleitung

GB Assembly instructions

FR Notice de montage

NL Handleiding voor de montage

CZ Montážní návod

IT Istruzioni di montaggio

RO Instrucțiuni de montaj



RU инструкция по сборке

PL Instrukcja montażu

SK Návod na montáž

HU Szerelési útmutató

TR Montaj talimatı











Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denumire • Ísim • Название

Alcora zerl.
SH46 Laro

Nr. • No. • N° • Номер • Č • Sz

Typ • Type • Tip • Típus • Tipo
Тип






Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denumire • Ísim • Название


Nr. • No. • N° • Номер • Č • Sz

Typ • Type • Tip • Típus • Tipo
Тип

- O-



**Fu1****2x****Fu2****2x****Wi****2x****BVR****1x****BVL****1x****LRF****2x****EW****4x****DR****2x****FS****2x**

A	B	C	D	E	F	G	H	J	K	J	
x20	x2	x2	x2	x2	2/x2	x2	3/x2	x2	2/x2	x2	
M6x20	M6x35	M6x45	4,5x45	M8x45	M8	M6x35	M6	M5x16	M5	4,5x16	3




Alcora zen mi BK_SH46 Laro

B



1




A

C

1









2





2

DR









Alcór'a_zer_mit_Bk_S446_Laro						
L	M	N	Achtung! Schrauben nicht überdrehen			GB Watch Out! Do not over tighten
			FR Attention! Ne serrez pas trop	NL Let Op! Niet te vast	IT Atteno! Non stringere	RU Осторожно! Не затягивайте
			CZ Dávej Pozor! Nepřetahujte	RO Ai Grijia! Nu strângeți	PL Uważaj! Nie dokręcać zbyt mocno	SK Dávaj Pozor! Nepřetahujte
			HU Vigyázz! Ne húzza túl	TR Dikkat! Üzerinde sıkmayın		

